






Pattern No.: 1110381 - Yarn Quality Tandem left V-Teil(e)

A	B	C	D	E	D	C	B	A
	>	8A 1x Nm 28/2 Residual yarn -			8			
					7			
					6			
Friction >	>>	5A 2x Nm 30/2 Cashwool 100% WV Zegna Baruffa			5			
					4			
Friction >	>>>	3A 3x Nm 30/2 Cashwool 100% WV Zegna Baruffa			3			
	>	2A 1x Comb thread -			2			
	>	1A 1x Draw separation thread -			1			

A: Feed Wheel B: Feed C: Yarn count D: Feeder E: Track



Normal



Normal-ADF



Intarsia type 1



Intarsia type 2



Plating Yf. N



Double-Arm Plating Yf.








Plating_w_2->1



Plating_w_2->2

Pattern No.: 1110381 - Yarn Quality Tandem right V-Teil(e)

A	B	C	D	E	D	C	B	A		
				8				8B 1x Nm 28/2 Residual yarn -	<	
				7				7A 1x Nm 30/2 Cashwool 100% WV Zegna Baruffa	<	Friction <
				6						
				5						
				4						
				3				3B 1x Nm 30/2 Cashwool 100% WV Zegna Baruffa	<	Friction <
				2				2B 1x Comb thread -	<	
				1				1B 1x Draw separation thread -	<	

A: Feed Wheel B: Feed C: Yarn count D: Feeder E: Track



Pattern No.: 1110381

Other Requirements:

Muster nicht vor Technik laden.

Don't load pattern before technique.
